

1/21




FIG.3

~298 -293~294 -295 ~ 296 215 291 220 292 297 210 .214 ,219 NEXT PLAYBACK / NUMBER PLAYBACK PATH INFORMATION TABLE PLAYBACK CONTROL INFORMATION CONTENT NAME · Opening.mpg Interview.mpg Purchase.mpg Trailer.mpg 221 Warning.mpg Menu.mpg Movie.mpg Trailer.mpg 213 218 PLAYBACK NUMBER ∞ 212





FIG.5

BUTTON DATA TABLE

249 SELECTED | GRAYED-OUT PLAY DATA PLAY 248 **PURCHASE** DATA PLAY PLAY 240 247 UN-SELECTED DATA PLAY RIGHT BUTTON NUMBER 2 ന 4 **BUTTON DATA** LEFT BUTTON NUMBER 2 \mathfrak{C} LOWER BUTTON NUMBER ~ ന 4 UPPER BUTTON NUMBER 4 2 3 243 PLAYBACK NUMBER 242~2 ∞ ന / BUTTON NUMBER 2 \mathfrak{C} 4 5/21

PCT/JP2005/003829

FIG.6



WO 2005/086159 PCT/JP2005/003829

FIG.7




FIG.8

			7266		_272		,773) 	274	
	270	RIGHTS MODE INFORMATION	(-) 00	(-) 00	01 (MODE A)	(-) 00	(-) 00	01,10 (MODES A AND B)	10 (MODE B)	
_E	265	COPYABILITY INFORMATION	01 (Once)	10 (Free)	00 (Never)	00 (Never)	00 (Never)	00 (Never)	00 (Never)	
KEY CONTROL INFORMATION TABLE	KEY CONTROL INFORMATION 264	PLAYABILITY INFORMATION	\ 1 (PLAYABLE)	1 (PLAYABLE)	0 (UNPLAYABLE)	1 (PLAYABLE)	1 (PLAYABLE)	0 (UNPLAYABLE)	0 (UNPLAYABLE))
KEY CONTROL IN		KEY GENERATION INFORMATION	(MEDIA KEY)	00 (MEDIA KEY)	O1 (COMPOSITE KEY)	00 (MEDIA KEY)	00 (MEDIA KEY)	10 , (RIGHTS KEY)	10 (RIGHTS KEY)	268 269
	2 263	CONTENT	1111	2222	3333	4444	5555	9999	7777	267 268
	262	CONTENT	, Opening.mpg	Trailer.mpg	Movie.mpg	Warning.mpg	Menu.mpg	Making.mpg	Interview.mpg	
			761	- - - (3/21					

FIG. 9


MEDIA INFORMATION TABLE


≥ 280

	MEDIA INFORMATION							
	DEVICE INFORMATION	ENCRYPTED MEDIA KEY						
281~	0001	qwerty	2					
	0002	asdfgh						
	0004	zxcvbn						
	0005	uiop@[·					
	0006	jkl;:]						
	0007	m,./¥¥						
	:	:						


FIG.10


RIGHTS INFORMATION TABLE








11/21




















FIG. 20

